



# RAINDOG BUILDING PRODUCTS

## Installation instructions for Raindog Mounting Plates



STEP 1



STEP 2 and 4

1. Locate the area where the plate is to be installed. Place the building paper or house wrap on the wall in accordance with your local building code. Cut the building paper around the box and staple in place leaving the area around the top of the plate open to slide in a second piece of paper (see step 2) Snap the plate apart into two pieces and install the bottom of the plate right side up with the rainscreen channel at the top of the plate and the water evacuation spout at the bottom.
2. Slide a second sheet of paper over the plate (about midway) and underneath the upper sheet of the building paper making sure the paper covers the top of the plate. This will prevent water from flowing between the paper and under the plate. Cut the paper around the top of the mounting plate. Staple it in place.
3. Install the siding taking care not to allow it to touch the side of the mounting plate. Leave a small gap for expansion and contraction.
4. Install the top of the plate by snapping the connectors into their receptacle.